

# Integration of a Smoke and/or CO Detector into the F-Series Gen<sup>2</sup> Heat Alert System

## Electrical Connections

The power to the detector should be connected to a constant source. With the connections shown in the drawing below, the detector will activate the auxiliary input of the Control POD and trigger an alert. The drawing below is only an example orientation of the termination connectors. Please see the individual device instructions for the actual orientation.

- Wire the +/- contacts to a constant vehicle battery voltage.
- Jump the positive contact to the normally open (NO) contact.
- Connect the grey/black wire from the F-Series' Vehicle Interface Harness to the common (COM) contact.

